


Accessories		
AL	AL1 + MRB	Trip Alarm Contact 1a + Manual Reset Button
A2	AL1 + AL2 + MRB	Trip Alarm Contact 2a + Manual Reset Button
C	C	Counter
S	CS2	Charge Switch Communication
B	B	On/Off Button lock
M	MI	Mechanical Interlock
D	DI or MOC	Door Interlock or Mechanical Operated Cell Switch
K	K1	Key Lock
K2	K2	Key Interlock Set
K3	K3	Double Key Lock
R	RCS	Ready to Close Switch
T	TM	Temperature Alarm
E	ADM	Automatically Discharge Mechanism
H	SHT2	Double Shunt coil

Note) Other accessories should be ordered separately. (Refer to 50page)


Ordering

Susol

Cradle



Trip relay



Note) 1. Ground fault (default)
 2. Measurement, Communication, ZSI, Remote reset, Digital output. (It is only available with control power supply)
 3. Voltage module (P, S type, default)